



074 KINETIC FISHING SPEAR

For video instructions see www.youtube.com/user/buckknivestv

MOUNTING STICK TO SPEAR

For best results, we recommend using a straight stick 2" in diameter or smaller

1. Remove protective covers from the spear.
2. Both pieces are interlocking. Connect the pieces to create a cross-like pattern
3. Using the paracord (included), wrap a tight lash 6-8 rows about 6"-10" from the thicker end of the stick
4. With the chisel side of the spear inserted into the thicker end of the stick, strike the stick down against a solid surface until the spear is wedged evenly 2"-3" deep. The action of the chisel forcing itself into the wood will tighten up the paracord knots even tighter to hold very securely.
5. When driving spear into the wood, make sure the wood gets up to the wedge forcing the pieces to lock in and not move against the main piece
6. The plastic protective covering can be assembled into a cross pattern that can be dropped over the spear

